

INSTRUCTIONS

KIT

1. These kits should be installed into a pre-assembled cabinet and can be fitted to operate both horizontally or vertically. The door can be fitted to the cabinet sides as shown in these instructions.

FITTING THE SPIRALS

2. Decide on the position of the spirals. The spirals can be fitted behind a face panel as shown, or you can fit a pelmet piece to cover the curve of the spiral (minimum required is 60mm). Screw the spirals into place using the screws.

TIP: Make sure the screws are not too long for the thickness of the panel.



TRACK

3. Measure the length of track, to see if it fits into the space required.

If the track is too long, then cut to size.

DO NOT FIT THE TRACK until after step 4.

INSERT THE DOOR

4. Slide the door fully into the spirals



FITTING THE STRAIGHT TRACK

5. The track can be stuck on with the supplied double-sided tape. You can also drill through the flange to screw into position. Three holes are more than sufficient for track up to 750mm long. Peel the backing off the double-sided tape. Slide the track up to the spirals and press firmly into position. You can then fit using the screws if desired.

INSTRUCTIONS



FIT THE STOPS AND MAGNETIC TAPE

6. Check that the door operates correctly.

Fit the two plastic stops using the screws to the rear of the face panel. Fit them at least 10mm down from the edge so that when the door is lowered it stops in the correct position.